

Dr. Fixit Samshield XL 1500/2100



CROSS LAMINATED SBS SELF ADHESIVE WATERPROOFING MEMBRANE

Description

Dr. Fixit Samshield XL is a SBS self adhesive waterproofing membrane based on a tropical grade of polymer modified bitumen. The bitumen compound is laminated onto an impervious, non-perforated, HDPE **Valeron®** film. The membrane is protected on the self adhesive side with a silicone coated release film.

Typical Applications

Dr. Fixit Samshield XL used as waterproofing and damp proofing intended for concrete protection. It may be used for horizontal and vertical application and as a damp proofing course for tanking below ground structures, subways, retaining walls etc.

Features

- Specially formulated for tropical climate grade.
- Provides protection against water and vapour.
- Self adhesive, requires just peeling off the silicone film and sticking to the surface.
- Excellent adhesion to vertical and horizontal surfaces.
- Excellent resistance to chlorides, sulphates, alkalis and acids.
- Good tear and puncture resistance.
- Excellent tensile strength.

Method of Application

Application procedure may vary slightly depending upon site conditions. The general recommended guidelines for the application of the self adhesive waterproofing system are as follows:

1 SURFACE PREPARATION

The surface shall be cleaned thoroughly of all contaminants like dust, traces of curing compound, oil and grease. All surface imperfections, protrusions, structurally unsound and friable concrete must be removed and repaired with a suitable concrete repair mortar.

2 PRIMING

Apply **Dr. Fixit Torchshield Primer** @ 4-6 sq.mtrs./litre to a clean, smooth and dry surface by brush or roller. Allow the primer to dry prior to the application of the membrane. As the viscosity of the primer is low, it easily penetrates into the concrete pores which promote the adhesion between the membrane and the concrete surface. In addition to that the primer also acts as a binder for the dust which gets accumulated on the concrete surface even after cleaning.

3 ALIGNMENT

Start the installation of all membrane plies from the low point, so that the flow of water is over or parallel to the plies, but never against the laps. Begin membrane application by unrolling the roll of **Dr. Fixit Samshield XL** membrane and aligning the side laps.

Application

Peel off the release film from the self adhesive side and start unrolling the membrane and press it to the surface. Smoothen the membrane from the center to the edges with a wooden press in order to remove entrapped air. Furthermore, an iron roller shall be used for rolling on top of the applied membrane to ensure a proper and strong adhesion of the bitumen compound with the base surface. Side overlaps shall be a minimum of 75 mm on the selvedge and end overlaps 100 mm.



Protection

The membrane shall be protected immediately after application from damage, due to ongoing site activities or from sharp aggregates during backfilling by a tough, weather, warp and rot proof asphaltic protection board. Alternatively, on horizontal areas the membrane can also be protected by laying a cement sand screed (50 mm).

Technical Information

PROPERTIES	VALUES		TEST STANDARDS
Thickness (mm) (XL 1500/2100)	1.6	2.1 ± 5%	DIN EN 1849-1
Mass per unit area, (kg/m ²) (XL 1500/2100)	1.9	2.3 ± 10%	DIN EN 1849-1
Top Surfacing	Cross Laminated HDPE Valéron ® film		
Softening Point, (R&B) (°C)	> 105		ASTM D 36
Tensile Strength (L/T), (N/mm ²) Film	L - 34-50 T - 40-56		ASTM D 882
Elongation (L/T), (%) Film	L - 200-260 T - 160-200		ASTM D 882
Tear Resistance (L/T), (N) Film	L - 240-440 T - 220-400		ASTM D 1004
Peel Adhesion strength, (L/T), (N/ mm) Primed Substrate Self	> 1 > 1		ASTM C 794
Puncture Resistance, (N)	> 200		ASTM E 154
Hydrostatic pressure	> 50 m (5BAR) No leakage		BS EN 12390 (Part 8)
Low temperature Flexibility	- 15°C		ASTM D 1970
Crack Bridging Ability, (mm)	> 1.5		ASTM C 836

SUPPLY		
Dr. Fixit Samshield XL	1.6 mm	1 m x 10 m, WT 19 kg*
	2.1 mm	1 m x 10 m, WT 23 kg*
Dr. Fixit Torchshield Primer		20 ltr
*Approximate Weight		

Handling

Dr. Fixit Samshield XL membranes are supplied in rolls of 1m x 10mtrs. The rolls are packed in loose corrugated boxes to avoid damage during transit or during storage at sites. Care should be taken when storing the membranes on sites and should not be kept within close proximity of any sharp or protruding edges to avoid puncturing or damaging the membrane.



Shelf Life

Dr. Fixit Samshield XL membranes must be stored in a shaded area on wooden pallets neatly covered by a thick fabric and tied securely in a manner that will minimize exposure to sunlight and UV rays. The membrane shall be protected from all source of heat.

The shelf life is 18 months if stored as per the recommendations. Excessive exposure to sunlight, UV rays and other source of heat will result in considerable deterioration of the product and reduce its shelf life.

Health & Safety

Dr. Fixit Samshield XL contains tacky bitumen compound and can adhere to human skin during application. Bitumen stains can be removed by using a cloth dipped in a solvent. In case the affected area is sensitive one, seek medical assistance immediately.

Other Products Categories available

Dr. Fixit brings you the widest range of Construction Chemicals



Pidilite Industries Limited
Construction Chemicals Division
Ramkrishna Mandir Road, Post Box No. 17411
Andheri (E) Mumbai 400059 INDIA
Tel +91-22-2835 7000 • Fax +91-22-2835 7008
www.drfixit.co.in • info@drfixit.co.in
Dr. Fixit Advice Centre (Toll Free No.) 1800 209 5504

DISCLAIMER The product information & application details given by the company & its agents has been provided in good faith & meant to serve only as a general guideline during usage. Users are advised to carry out tests & take trials to ensure on the suitability of products meeting their requirement prior to full scale usage of our products. Since the correct identification of the problems, quality of other materials used and the on-site workmanship are factors beyond our control, there are no expressed or implied guarantee / warranty as to the results obtained. The company does not assume any liability or consequential damage for unsatisfactory results, arising from the use of our products.